


RRI-0529S

# AUTOMATIC SHUT-OFF SCREWDRIVER



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	AS00501	Motor Housing	37	AS000137	Reset Pin
2	61249	Pin	38	AS000138	Pin (1/16"X11)
3	AS00503	Air Inlet	39	AS000139	Trip Slide
4	AS00510	Shut-off Valve	40	AS000140	Spring
5	AS00509	Shut-off Valve Seat	41	AS000141	Plug
6	AS00530	Reverse Valve	42	52827	Internal Ring (RTW-22)
7	706107	O-Ring (2)	43	AS000143	Steel Ball (4) (3/16")
8	AS00508	Shut-off Valve Spring	44	AS000144	Spring
9	OR02500100	O-Ring	45	AS000145	Spring
10	AS00521	Reversing Valve Knob	46	AS000146	Cam Spindle
11	AS000117	Spring Pin	47	AS000147	Cover
13	AS000113	Ball Bearing (2)	48	AS000148	Bushing
14	AS000114	End Plate	49	AS000148	C-Ring (5103-43)
15	AS00415	Rotor	49	AS000149	Spring
16	AS000116	Rotor Blades (4)	50	AS000150	Thrust Race (2) (TRA-815)
17	30117	Spring Pin	51	AS000151	Roller Thrust Bearing (NTA-815)
18	AS000118	Cylinder	52	AS000152	Adjustment Lock Ring
19	AS000119	Front End Plate	53	AS000153	Adjustment Nut
20	AS00420	Motor Spacer	54	AS000154	Spindle Bushing
21	AS20534	Push Needle (120.2L)	55	AS000155	Ball Retainer
22	AS00422	Internal Gear	56	AS000156	Spring
23	AS00423	Planet Gear (3)	57	AS000157	Washer
24	AS00424	Pin (3) (3/32"X18.8)	58	AS000158	Adjustment Cover
26	AS00426	Work Spindle	59	AS00559	Clutch Housing
30	070130	Ball Bearing (77R6ZZ)	60	AS000161	Retaining Ring (ISTW-11)
31	AS00580	Clamp Nut	61	AS000167	Spring
32	AS00550	Muffler Material	62	AS000112	Retainer Ring
33	AS00507	Exhaust Diffuser	63	52245	Steel Ball (13) (3/32")
34	40145	Steel Ball (1/8")	64	AS00552	Rubber Grip
35	AS000135	Clutch	65	AS00582	Hook
36	AS000136	Pin (1/8"X9.6)	66	AS000163	Screwdriver (#2) (22.8X2)
			67	52235	O-Ring