

TPB-501SV PAVING BREAKER

8th edition

				MUST REPLACE 100%	Spare Parts Service Chart								
				HIGH WEAR 70%									
				MEDIUM WEAR 50%									
				LOW WEAR 30%									
				NON WEAR 10%									
				SUBJECT TO EXTERNAL DAMAGE									
Symbol No.	Parts No.	Q'ty Req.	Description	This service chart is a guide to expectant life of component parts. The replacement levels are based on average tool usage over a one year period.									
1	410370490	1	Back Head					X					
4	410231150	1	Valve				X						
5	131101051	1	O- Ring P- 49	X									
6	131103039	1	O- Ring S- 50	X									
7	410231180	1	Valve Cover					X					
9	131712055	4	Hex Socket Bolt M12X55					X					
10	131301012	4	Spring Washer M12					X					
12	130505048	1	Polyurethane Rubber Ball 3/4					A					
13	136601010	2	Rubber Grip					X					
14	410227C11	1	Valve Pin					X					
15	410227280	1	Valve Pin Bushing					X					
16	130801038	1	Valve Pin Spring			X							
17	410227310	1	Throttle Lever					X					
18	410227330	1	Throttle Lever Pin					X					
19	131313050	2	Coned Disk Spring H- 25					X					
20	410362800	1	Spacer Ring					X					
21	410370010	1	Cylinder					X					
22	130604040	3	Spring Pin 4X40					X					
23	410362040	1	Piston			X							
24	410350580	1	Tappet				X						
25	410370590	1	Tappet Seat					X					
30	410370530	1	Front Head 1- 1/8					X					
30	410371530	1	Front Head 1- 1/4					X					
31	130801062	1	Retainer Plunger Spring			X							
32	410350650	1	Retainer Plunger			X							
33	410350610	1	Steel Retainer	X									
34	130616060	1	Spring Pin 16X60			X							
35	130610060	1	Spring Pin 10X60			X							
36	410350540	2	Front Head Bolt					X					
37	130801063	2	Front Head Bolt Spring					X					
38	410350560	2	Plain Washer					X					
39	134304016	2	Hex Slotted Nut M16					X					
40	130604022	2	Spring Pin 4X22					X					
44	410362190	1	Valve Chest					X					
50	130400043	1	Parallel Pin 4X19.8					X					
51	131117018	1	O-R ing AS568-018	X									
52	130803144	1	Socket Retaining Ring					X					
55A	410231E60	1	Air Inlet Swivel (S)					X					
55B	136801001	1	Air Inlet Screen					X					
55C	131103019	1	O- Ring S- 24	X									
56	410231390	1	Air Inlet Swivel Nut					X					
57	131101033	1	O- Ring P- 32	X									
58	410231410	1	Air Inlet Swivel Spacer					X					
60	410136D60	1	Back Head Cap			X							
61	130606044	1	Spring Pin 6X44					X					
62	410136A81	1	Center Pin					X					
63	410136C90	1	Center Pin Ring					X					
65	410136070	1	Lever Handle					X					
66	410227080	1	Handle					X					
67	130801064	2	Handle Spring			X							
68	410227760	1	Stop Lever					X					
69	130801034	1	Stop Lever Spring			X							
71	410370C80	1	Muffler (Pair)					X					
72	132405240	8	Screw W/Washer M5X40					X					
73	134602005	8	Serrate Flange Nut M5					X					

This service chart is a guide to expectant life of component parts.
The replacement levels are based on average tool usage over a one year period.

Example : For 10 tools in use : 10
must —replace items will be required per year,
7 high wear items, etc.

Note: Quantities must be increased if the tool
is in more service or continuous usage.

LEGEND

X — Type of wear, if no other comments apply.
A — Easily lost or damaged during disassembly
and reassembly.

TPB-501SV PAVING BREAKER

