


RRG-1040AL CUT OFF TOOL



Index No.	Parts No.	Description	Index No.	Parts No.	Description
1	50-520001	Motor Housing	34	5L-507143	Disc Cover
2	30102	Spring Pin (3x24L)	35	5L-507135	Button Seat
3	50-520003	Air Inlet	36	5L-507136	Nut
4	5J-842304	Throttle Lever	37	5L-507137	Screw (M4x12L)
5	50-520005	Valve Shaft	38	5L-507138	Roller Shaft
6	70107	O-Ring (4.8x1.9)	39	5L-507139	Spring
7	5B-321107	Connector	40	5L-507140	Washer
8	5L-507108	Spring	41	5L-507141	Washer
9	50-520008	Valve Spring	42	5L-507142	Oil Felt
10	50-520010	Plug	43	40128-21	Spring Pin (Ø2x18L)
11	0684ZZ	Ball Bearing (684zz)	44	5B-321144	Nut
12	5L-507112	Bushing	45	50-520002	Decoration Ring
13	70123	O-Ring (11.8x2.4)	46	030113	Ball Bearing (626zz)
14	5K-3011B14	Rear End Plate	47	72017	Spring Pin (3) (Ø2.5x6L)
15	5B-321115	Rotor	48	51541	Spring
16	5K-3011B16	Rotor Blade (4)	49	051220	Ball Bearing (6000zz)
17	5L-507117	Screw (M4x20L)	50	OR04000200	O-Ring (40x2)
18	5L-520018	Cylinder	51	40126	O-Ring (35.5x2)
19	5B-321119	Front End Plate	52	5L-520052	Grip
20	5K-3011B20	Connector Nut	53	OR03105200	O-Ring (31.5x2)
21	5L-507121	Flange	54	5L-520013	Clamp Nut
22	5L-507122	Bevel Gear	55	WW30	Wave Washers (4) (WW-30)
23	5L-507123	Bevel Gear	56	STW-15	Retaining Ring(2) (STW-15)
24	5L-507124	Lock Bar	57	5J-842350	Safety Bar
25	5L-507125	Bushing	58	STW30	Retaining Ring (STW-30)
26	5L-507126	Flange Nut	59	PN04001108	PIN (4x11.8)
27	5L-507127	Lock Nut	60	OR01104103	O-Ring (11.4x1.25)
28	5L-507128	Front Housing	61	0728121	Ball Bearing (2) (698zz)
29	5L-507129	Connector Pipe	62	030120	Ball Bearing (608zz)
30	5K-2011B44	Nut	63	06903ZZ	Ball Bearing (6903ZZ)
31	5L-507131	Lock Nut	64	50-520011	Diffuser
32	654247	Screw (M6x16L)	65	10014	Hex-Key Wrench (4mm)
33	5L-507133	Stop Button	*66	5L-3011B39	Cutting Wheel (4")

*Optional parts

5L-5200-0001